




Setting Instruction SOP 9035

Thank you for purchasing an original ZENO Timekeeper. To ensure correct use, please read these instructions carefully:



Specifications

Precision Swiss self-winding movement (automatic), time, day and date indication, 30 jewels, 21' or 28'800 pulsation per hour, Incabloc anti-shock system, Nivaflex spring, fine setting, tight tolerance of adjustment, power reserve till 30 hours

A 24-hour indication (Dual time)

B Date indication

C Power Reserve indication

Setting Time + Calendar


1 neutral position
= winding position

2 calendar adjustment position
B date indication: turn crown clockwise ☺

3 hand setting and second stop position
- Adjust hour and minute by turning the crown

Dual time

Depress the recessed button at 10 o'clock



Warning: Correction cannot be effected between 8pm and 2am. While turning the hands please observe that date will change at 12pm (midnight).

The watch will now be set correctly and running.

The automatic movement will keep the watch wound as long as the watch is worn.

Be sure to use the watch with the crown pressed in (normal position). If your watch has a screw-type crown, be sure to tighten the crown completely. Do not operate the crown with wet fingers or when the watch is wet. Water may enter the watch and compromise water resistance. If moisture has entered the watch, or if the inside to the crystal is fogged up and does not become clear within a day, or seawater enters the watch, immediately take the watch to a Zeno Service Centre for repair. Leaving the watch in such a state will allow corrosion to form inside. Keep your watch clean. Dust and dirt tend to collect in gaps in the back of the case or band. Accumulated dust and dirt may cause corrosion and soil your clothing. Clean the watch occasionally. Use a soft dry cloth to wipe off dirt, perspiration and water from the case and crystal. Do not use the watch in places where it is exposed to high temperature. Doing so may result in deterioration of the watch or parts. Do not place the watch to a magnet. Timekeeping will become inaccurate. Store your watch in a dry place when you are not using it. Further information see guarantee card!

Have you got a problem with your watch?

Your nearest ZENO Represent is usually the best place to contact for help, and it should certainly be the first.

1. Please contact first your ZENO dealer and ask for a Service-Centre in your country. (You will find the address of your dealer in the guarantee certificate)
2. In case there is no Service-Centre in your country, please send the watch back to your dealer or to the worldwide Service-Centre:

ZENO-WATCH BASEL
Service-Centre - P.O. Box
CH-4013 Basel (Switzerland)

Please send your watch, carefully packed, together with \$ 15.0 in cash (to cover return postage and handling charges), the guarantee certificate, completed with your correct name and return address. For costume reasons please declare the goods to be R E P A I R E D !!!

Repairs without original and signed international ZENO guarantee certificate or after the guarantee period will be charged. Owner will be charged for postage, insurance and such costs as may be incurred outside the normal repair costs under the guarantee. For those customers requiring their watches to be repaired in countries other than those where the purchase was originally made, repair services are available though it is to be acknowledged that it might take somewhat longer than normal.

Our service is, of course, also available after the guarantee period has expired for repair and maintenance work against an appropriate charge. [Payment in advance]. Sometimes it is cheaper to contact first a qualified watchmaker in your area. (He must have experience with Swiss Watches!) Please ask your watchmaker for a free estimate!

Please note that ZENO only ensures full warranty when the ZENO watch is bought directly from one of the authorized dealers. The warranty certificate must be properly stamped, signed with the dealer's name and show the exact date of purchase.

Only authorized ZENO retailer or other authorized Service Centres are qualified to ensure proper after-sales service and are authorized to provide the warranty services in accordance to ZENO quality standards.

The water resistance is only guaranteed if the watch is declared by "waterproof" and the watch has not been subjected to severe shocks, the crystal and crown are not damaged, and the instructions have been carefully followed:

WATER RESIST (water protected) = This watch is protected against water drops (the watch has to be protected against water!)

WATERRESISTANT 30M (3ATM) = This watch you can use for car washing, bathing, shower, mountain climbing, parachuting, hang gliding, or skiing - it is resistant against perspiration, water vapour, rain drops.

WATERRESISTANT 100 M (10ATM) = This watch you can use for water sport, snocheling, swimming, car washing, bathing, shower, mountain climbing, parachuting, hang gliding, skiing - it is resistant against perspiration...

WATERRESISTANT 200 M (20ATM) = This watch you can use for diving (without equipment), water sport, snocheling, swimming, car washing, bathing, shower, mountain climbing, parachuting, hang gliding, skiing - it is resistant against perspiration, water vapour, rain drops.

In case your watch needs to be repaired or to raise claims under a guarantee, please contact the point of sales.

Please be sure to check the ZENO-WATCH Web site for the latest listing of World Wide Service Centres at www.zeno-watch.ch